


**BERM** 1  
NOT TO SCALE 3 4



**ISOMETRIC**

**TYPICAL SECTION**

**NOTES:**

1. PREPARE THE SUBGRADE AS SHOWN ON THE CONSTRUCTION DRAWINGS.
2. DO NOT COMPACT SUBGRADE.
3. PROVIDE WOVEN HIGH STRENGTH STABILIZATION GEOTEXTILE (WNFAB 270HP).
4. EXPAND THE GEOWEB SECTIONS INTO POSITION AND CONNECT THE END TO END AND INTERLEAF CONNECTIONS WITH ATRA KEYS.
5. PLACE THE SPECIFIED INFILL MATERIAL INTO CELLS AND TRACK UNTIL CELL IS FILLED AND SETTLEMENT OF INFILL IS NEGLIGIBLE.

**GEOWEB DETAIL** 2  
NOT TO SCALE 3 4



www.tetrattech.com  
661 ANDERSEN DRIVE - FOSTER PLAZA 7  
PITTSBURGH, PA 15220  
T: (412) 921-7090 | F: (412) 921-4040

REVISIONS			
NO.	BY	DATE	REMARKS
1	TD	11/30/16	REVISED FOR DEP TECHNICAL COMMENTS
2	TD	02/06/17	REVISED FOR DEP TECHNICAL COMMENTS

SUNOCO PIPELINE L.P.  
SINKING SPRING, PENNSYLVANIA  
  
HOUSTON INJECTION STATION

ESCGP-2 POST CONSTRUCTION STORMWATER PLAN

CONSTRUCTION DETAILS

DATE:	11/2/16
PROJECT NO.:	PB-00136
DESIGNED BY:	RS
DRAWN BY:	BH
CHECKED BY:	RS
COPYRIGHT TETRA TECH INC.	
<b>C-4</b>	
SHEET	4 OF 4