

# PA DEP Stormwater Manual Updates

WRAC

Robert Traver, PhD, PE, D.WRE, Villanova University

Mark Bowen, PE, NTM Engineering

Amanda Hess, PhD, PE, Villanova University

November 2022

# Protect Waters of the Commonwealth

## Purpose:

*“This guidance establishes standards for the management of stormwater through the implementation of SCMs and other measures to comply with the regulatory requirements under 25 Pa. Code Chapter 102. This guidance may also be used for other purposes where the intent is to design, install, and maintain SCMs.”*

## Overarching Principles

- Better Science at all stages
- Focus on Resilience
- Focus on Agility –
  - Enabling approaches that meet Pa. Code Chapter 102 for difficult sites
  - Enable approaches that can be expected to surpass their design objectives, and / or contribute to other benefits to the community.
  - Embrace simpler but appropriate approaches where appropriate.
- Incorporate the ability to update the Manual

Commonwealth of Pennsylvania



## Pennsylvania Post-Construction Stormwater Management (PCSM) Manual

Bureau of Clean Water  
Pennsylvania Department of Environmental Protection  
400 Market Street, P.O. Box 8774  
Harrisburg, PA 17105-8774  
[www.dep.pa.gov](http://www.dep.pa.gov)

# How this is addressed

- Acknowledges and Addresses Climate Change
- Right SCM(s) for the job
  - Right design expertise
  - Understanding of site infiltration capabilities
  - Promote resilient, correctly sized SCM tailored to the soil capacity, precipitation patterns and watershed
  - Landowner must be able to maintain
- System Approach
  - Site Evaluation, Design, Construction, Inspection, Maintenance
- Separate Volume / Water Quality SCM from Rate Control
- Expand Stormwater Analysis Methods

**Nothing works when not designed, built,  
and maintained correctly...**



**or**

**When Designed, Constructed, and  
Maintained correctly we expect it to work**



# Stormwater Analysis Methods

- Volume Management Analysis Methods
  - Design Storm
  - Continuous Simulation
  - Water Balance
- Water Quality Management Analysis Method
  - mass-load based
  - linked to volume method
- Peak Rate Management Analysis Methods
  - Design Storm
  - Storm of Record



# General Stormwater Manual Layout

## Chapters

- 1: Introduction
- 2: PCSM Requirements
- 3: SCM Technical Guidance


## Appendices

- A: Precipitation
- B: Soil Physics, Characterization, and Infiltration Testing
- C: Karst Terrain
- D: Evapotranspiration
- E: Hydrologic Budget and Water Balance
- F: Volume Management Analysis Methods
- G: Water Quality Analysis Methods
- H: Peak Rate Analysis Methods
- I: Vegetation for Use in Stormwater Management
- J: SCM Components and Specifications
- K: Construction Inspection, Operation and Maintenance
- L: Definitions and Acronyms
- M: Errata Sheet

# Better Science at All Stages

Engineer,  
Land Surveyor  
And Geologist  
Registration Law  
Act of May 23, 1945,  
P.L. 913, No. 367 Cl. 63

- Design Includes Licensed Professionals
- PCSM Plan Preparer – “*Trained and Experienced*” Chapter 102.8(e)
  - Not required to be a “Licensed Professional.”
  - Must engage Licensed Professionals
    - Professional Engineers – Must oversee computations
    - Land Surveyors
    - Geologists
    - Soil Scientists
- Certain Designs Require Professional Services
  - Karst
  - Infiltration “Under Certain Circumstances”
  - Floodplain Restoration
  - Structural SCMs




# Better Experience at All Stages

- Licensed Professional Oversight of Construction

The permittee should enter into an agreement with the licensed professional that specifies how the licensed professional will act as the permittee's representative and how the owner will assure that the operator addresses any concerns raised by the licensed professional promptly and completely.

- Contractors engaged to construct infiltration SCMs should have verifiable experience in the construction of similar facilities.





# Pennsylvania Climate Projections for 2022 to 2050

- 8% increase in annual rainfall
- 14% increase in winter precipitation
- 3.3°C warmer
- More storms >1.2 in of rainfall in 1 day
- Expected increase in intensity and frequency of cloudburst events
- No. of days with >3 in of rainfall is projected to increase:
  - 52% by mid-century
  - 93% by end-of-century

In general: warmer, wetter, and more intense



# Extreme Rainfall Adjustment

- Use 90% confidence level event rainfall depth
  - NOAA Atlas 14 Point Precipitation Frequency Estimates
  - 10% to 20% higher than what is used today
  - Inlet design
- Chesapeake Bay IDF Curves – Rand Corp. 2021
- EPA SWMM Climate Adjustment Tool (SWMM-CAT)



**POINT PRECIPITATION FREQUENCY (PF) ESTIMATES**  
WITH 90% CONFIDENCE INTERVALS AND SUPPLEMENTARY INFORMATION

PF tabular

PF graphical

Supplementary information




[Print page](#)

## PDS-based precipitation frequency estimates with 90% confidence intervals (in inches)<sup>1</sup>

Duration	Average recurrence interval (years)									
	1	2	5	10	25	50	100	200	500	1000
24-hr	2.70 (2.50-2.93)	3.26 (3.01-3.54)	4.12 (3.80-4.47)	4.84 (4.45-5.24)	5.90 (5.40-6.37)	6.80 (6.18-7.32)	7.77 (7.03-8.36)	8.84 (7.93-9.49)	10.4 (9.22-11.2)	11.7 (10.3-12.6)

- Use mean climate-adjusted storm depth

<https://midatlantic-idf.rcc-acis.org/>



## Selection Panel

Return Period

2-year ▼

Emissions Scenario

High RCP 8.5 ▼

Time Period

2020-2070 ▼


Area of Interest

Chesapeake Bay Watershed ▼

Percentile	10th	25th	Median	75th	90th	Atlas 14 Depth (inches)
County Change Factors:	1.04	1.06	1.11	1.16	1.22	
Duration	Projected 2020-2070 Depth (inches)					
24 hr	3.14	3.20	3.35	3.50	3.68	3.02

# Climate Change Incorporation – Design Storm

- NOAA 14 is outdated (no change since 2006)
- Use upper 90% confidence interval for 2-year/24-hour storm for NOAA




PDS-based		
Duration	1	2
5-min	0.347 (0.320-0.378)	0.414 (0.380-0.451)
24-hr	2.70 (2.50-2.93)	3.26 (3.01-3.54)

[https://hdsc.nws.noaa.gov/hdsc/pfds/pfds\\_map\\_cont.html](https://hdsc.nws.noaa.gov/hdsc/pfds/pfds_map_cont.html)


<https://midatlantic-idf.rcc-acis.org/>

# Continuous Simulation Modeling Example



# Climate Change Incorporation – Continuous Simulation/Water Balance

- Long-term climate change record is very difficult to determine and typically location based
- Recommends monthly SWMM CAT 1.1 Adjustments (near term & Warm/Wet) applied to precipitation
- Includes temperature impact on ET and infiltration
- Updated 8/3/2022






# Project Site & Limit of Disturbance

- **Project Site (Chapter 102.1)**



- The entire area of activity, development, or sale including:
  - the area of an earth disturbance activity
  - the area planned for an earth disturbance activity
  - and other areas which are not subject to an earth disturbance activity

- **Limit of Disturbance (LOD)**

- The boundary within which it is anticipated that earthmoving, including installation of BMPs, will take place.
- Emphasis in new manual is on minimizing land clearing and grading



# PROJECT SITE BOUNDARY



- Must enclose all earth disturbance, SCMs, and conveyances to SCMs that manage runoff from all earth disturbance, regardless of whether the SCMs are or are not on property owned or under the direct control of the applicant for a Chapter 102 permit.

Natural Landscape SCMs  
in NPDES Boundary



# Pre-Development Site Characterization


- Examine: Hydrology, Geology, Soils, Plants, Protected Species, Natural Landscapes, Surface Waters, Environmental Hazards
- Preliminary infiltration testing needed for entire site
  - One test for every 40,000 square feet
  - Geologic and Soils information needed
  - Groundwater information needed
- Identify areas that “Protect Surface Waters”
  - Riparian Buffers
  - Natural Landscape



# Infiltration Testing & Soil Characterization

Testing for infiltration capacity and Soil characterization is required during:

- Preliminary Site Evaluation
- SCM-Specific



# Infiltration Testing Requirements

Can use:

- Double Ring Infiltrometer Method
- Single Ring (Modified Philip-Dunne and Dual-Head Infiltrometers)
- Case Borehole (If conditions render the excavation of test pits impractical, due to existing structures, utilities, space constraints, depth of test, etc.)

Criteria	Number of tests required per infiltration test type		
	Double Ring	Single Ring	Cased Borehole
Minimum number of Tests for each SCM	5 tests	8 tests	8 tests
Or the following if more conservative	1 test per 4,350 square feet	1 test per 2,900 square feet	1 test per 2,900 square feet

# Confirmation Testing for Infiltration Capacity

Construction confirmation testing  
for infiltration capacity is...

For...

**Required**

Infiltration SCMs where the contractor does not meet the experience criteria (constructed at least 3 successful infiltration SCMs in the past 2 years).

All infiltration SCMs that have been converted from an E&S sediment trap or basin (regardless of contractor experience).

**Waived when all of these criteria  
are satisfied**

Infiltration SCMs that have not been converted from an E&S sediment trap or basin; and

The contractor meets the experience criteria (constructed at least 3 successful infiltration SCMs in the past 2 years); and

The permittee enters into an agreement with a licensed professional to regularly report to the permittee, and the permittee regularly enforces the recommendations of the licensed professional.

**Highly recommended/considered  
good engineering practice**

Infiltration SCMs where there is concern of compaction during construction.

Infiltration SCMs overlying soils with a saturated hydraulic conductivity of less than 0.57 inch/hour (upper range of HSG C soils).

Can be done by 1) a simulated runoff test, 2) inspection during and after a large storm event, or 3) infiltration testing methods

# Underdrain guidance based on soil

Designation for underlying soils	Geometric mean design sat. hydraulic cond. rate	Implications to SCM guidance
Limited	$\leq 0.25$ inch/hour	MRC is applicable due to infiltration limitations, but this does not negate the need to explore other SCM options
Marginal	$> 0.25$ and $\leq 0.4$ inch/hour	Use of infiltration-based SCMs is recommended unless there are structural or environmental reasons not to. Capped backup underdrain (preferably with an IWS) within infiltration-based SCMs is recommended.
Not limited or marginal	$> 0.4$ inch/hour and $\leq 5$ inches/hour	Use of infiltration-based SCMs is recommended*. Underdrains not recommended.
	$> 5$ inches/hour and $\leq 10$ inches/hour	Use of infiltration-based SCMs is recommended*. Licensed professional is required to evaluate the appropriateness of infiltration rates with respect to unintended flow paths. Underdrains not recommended.
	$> 10$ inches/hour	Use of infiltration-based SCMs is recommended*. Soil media should be placed on the underlying soils to limit this rate. Underdrains not recommended.

\*unless there are structural or environmental reasons not to

# PCSM Objectives

**Objective A** – Natural Landscape SCM's - wherever practicable

**Objective B** – Volume/quality management


- Through infiltration, evapotranspiration, and natural landscape SCMs

**Objective C** – Managed Release Concept (MRC)


- Includes a wider variety of SCM

**Objective D** –Rate Control

- Minimized by A through C
- In separate facility for larger projects



# PCSM Objectives by SCM






# Objective A: Protect & Preserve Natural Landscape Processes



Areas within the project boundary, or otherwise included in a stormwater permit application, that are preserved and protected by a recorded long-term stipulation for the purposes of providing stormwater management benefit.

- **Protected Natural Stormwater Features**
- **Preserved Natural Open Spaces**
- **Enhanced Natural Landscape SCMs**



# Objective B: Infiltration and Non-infiltration based

- Manage the net change for storms up to and including the 2-year/24-hour storm event for runoff volume and water quality (or Act 167 Plan) through SCMs that provide infiltration, ET, or capture and use SCMs to the extent practicable
- *Provide pretreatment in accordance with the guidance provided for each SCM*
- *Bypass of runoff from storm events that exceed the design capacity of PCSM Objective B SCMs is recommended.*







# Objective C: MRC

A PCSM strategy involving the capture, filtration, treatment, and controlled release of runoff from an SCM that may be used when there are environmental limitations on a project site and where natural landscape processes, ET and infiltration are implemented to the maximum extent practicable.


**Managed Release includes both:**

- **Controlled Release**
- **Geomorphologic Protection**
- **Internal Water Storage (IWS)**



# Resilience - Separate Volume/Water Quality (A,B,C) from Rate Control (D)

- Referred to in the 2006 Manual as “offline”
- Why?
  - Preserves the function of Volume and Water Quality devices to target storms smaller than design volume (typically 2-year/24-hour storm)
  - Reduces maintenance, promotes longevity
  - Reduces the footprint of the basins needed for peak rate control
- Manual acknowledges that this is not always possible



# Resilience - Separate Rate Control from Volume/Water Quality

- The storm that the SCM is designed to manage must reach the basin. The inflow component must be sized to accept the SCM design storm.
- Larger storms should be bypassed when Objective A, B,C capacity is reached
- A flow path for flows in excess of storm drain capacity is needed.



**DUAL DRAINAGE  
CONCEPT**



# Construction Inspection of PCSM SCM's

- **Purpose**

- Ensure site conditions match assumptions
- Ensure SCMs are constructed as designed

- **Licensed Professional Oversight**

- **Critical Stages** – Per 25 Pa. Code 102.8(f)(7), PCSM plan must identify inspection schedule for all critical stages, performed by a licensed professional



# Construction Inspection of PCSM SCM's

- **Infiltration New Major Critical Stages –**

- Post construction infiltration confirmation testing
- Final inspection, confirming no fines (particularly from construction dust) are in the SCM or its components
- Excavation to, and preparations of, infiltration surface
- Construction of any outlet pipes or structures, including the underdrain
- Conversion from temporary ESPC BMP (sediment basin) to permanent PCSM SCM

- **Chapter 3 - Critical Stages for Each SCM**






# Operation & Maintenance of PCSM SCMs

- **Routine Inspection** – Each SCM should be inspected annually and after storm events exceeding 2.5 inches of rainfall.
- **Routine Maintenance** – Performed on a scheduled basis; grass & vegetation management, sediment & trash removal
- **Corrective Maintenance** – Repairs that are typically more involved than what occurs during regular maintenance.



# PCSM in Karst Terrain

- Intensive predevelopment site investigation required
  - Desktop study including map of topography, soils, geography, etc.
  - Field investigation including documentation of any features not shown in desktop study, and search for local testimony from neighboring properties
  - Downstream analysis
- Full geotechnical and/or engineering report is required to be submitted to PADEP that includes findings of site investigation and approach to PCSM design






# PCSM in Karst Terrain

- **Pre-development analysis**

- Analysis of existing Infiltration
- Analysis of depression storage
- Evaluation of open caves
- Actual cover condition (not assumed meadow)


- **Post development**

- Pretreatment and filtration
- Limit infiltration to pre-development
- Limit off-site discharge to historic flow
- Separate rate control
- Karst MRC




# Volume, Water Quality and Peak Rate

- Three Volume methods:
  - PCSM Spreadsheet Design Storm Approach (current)
  - Water Balance (only for certain SCMs)
  - Continuous simulation (most recent 15 years)
- Water quality method
  - Tied to volume method
  - Mass Approach
- Peak Rate
  - Design Storm Approach →
  - Storm of Record Approach



# Volume Management Analysis Approaches- Water Balance

- Can include SCMs in combination with Harvesting and Use
- Design Storm method
  - 1-yr/10-min storage volume (recover in 3 days)
  - Release less than 0.05 cfs / acre for 1.2 inch two hr storm
- Water Balance method
  - Long-term, minimum time step of daily accounting
  - 90% of all 1.2 storms captured (adapted from Managed Release Concept)
- Geomorphological management (2-yr to 1-yr)



# Volume Management Analysis Approach – DEP PCSM Spreadsheet

- Compared 2-year/24-hour storm event from PA DEP Spreadsheet with LA RECARGA
- Spreadsheet – allows for static number of hours of infiltration and ET as void space
- LA RECARGA– allows for dynamic processes (ET and Infiltration)

**pennsylvania**  
DEPARTMENT OF ENVIRONMENTAL PROTECTION

DEP PCSM Spreadsheet  
Draft, October 2010

### Volume Control

Instructions General **Volume** Rate Quality CLEAR FORM

2-Year / 24-Hour Storm Event (NOAA Atlas)  inches Alternative 2-Year / 24-Hour Storm I  inches  
Alternative Source

Project Site **Pre-Construct** No. Rows  Automatically Calculate CN, Ia, Runoff and Volume

Land Cover	Area (acres)	Soil Group	CN	Ia (in)	Runoff (in)	Volume (cf)
TOTAL (ACRES):						0

Project Site **Post-Construct**

Land Cover	Area (acres)	Soil Group	CN	Ia (in)	Runoff (in)	Volume (cf)
TOTAL (ACRES):						0

IN VOLUME TO MANAGE (CF):

**Non-Structural BMP Volume Credits:**

☐ Pervious Undeveloped Areas EDIT (CF):

☐ Tree Planting Credit

☐ Other (attach calculations):

Structural BMP Volume Credit: Structural BMP:

DP No.	BMP No.	BMP Name	BMP DA (acres)	DA % Impervious	Vol. Retained to BMP	Inf. Area (SF)	Inf. Rate (in/hr)	Inf. Period (days)	Vegetated?	Media Depth (ft)	Storage Vol. (CF)	Inf. Credit (CF)	ET Credit (CF)
1													

ION & ET CREDITS (CF):

RELEASE CREDIT (CF):

CHANGE IN VOLUME TO MANAGE:

TOTAL CREDITS (CF):

PA DEP Spreadsheet

Vs.

**LA\_RECARGA**

### Los Angeles RECARGA

Version 1.0  
Bioretention/Raingarden Sizing Program

**Tributary Area Parameters**

Facility Area  4386 (sf)  
Tributary Area  1 (acre)  
Percent Impervious  100  
Impervious Depression Storage Depth  0.18 (in.)  
Previous CN  80

**Climate Data**

Simulation Type  Continuous  
Climate File Name  LAT19662037us

**Evapotranspiration Input**

Species Factor (ks)  0.4  
Density Factor (kd)  0.4  
Microclimate Factor (kmo)  1.6  
Landscape Coefficient (KL)

**Facility Inputs**

Soil Texture  Silt  Percolity  Depth   
Rooting Zone  6  
Leaky Sand  1.63  0.40  24  
Storage Zone  Sand  3.6  0.42  0  
Native Soil Layer  Silt Loam  13  0.45

**Results**

**Plant Survivability**  
(Less than 40 hours max. ponding in bioretention)

	Maximum Continuous (hrs)	Total (hrs)
Time Ponded	0	0
Number of overflows	0	0

**Precipitation**  [in] acre-ft

**Bioretention Inflow Source**  [in] over source area acre-ft

	Impervious Runoff	Pervious Runoff	Precipitation on Bioretention
	0	0	0

**Bioretention Water Balance**

	[in] over trib. + PO	acre-ft	%
Inflow	0	0	0
Runoff	0	0	0
Recharge	0	0	0
Evaporation	0	0	0
Underdrain	0	0	0
Ponded Water	0	0	0
Soil Moisture	0	0	0
Non-Runoff	0	0	0

**Output**

Output File ☐ Summary ☐ Detailed  
Output File Name  Project2000

**OPEN REFERENCE**

**OPEN USER'S MANUAL**

**CITY OF LOS ANGELES**  
**SANITATION**  
DEPARTMENT OF PUBLIC WORKS

Originally Developed by the University of Western Australia  
City & Environmental Engineering Water Resources Group  
Adapted by: Montgomery Brinkman, Technical Services, LLC for the City of Los Angeles, Department of Public Works, Sanitation Group  
Copyright 2009

**RUN SIMULATION**

**CLEAR RESULTS**


LA RECARGA

There is nothing stopping an applicant from using LA RECARGA or another model for this type of approach in conjunction with the spreadsheet.



# Volume Management Analysis Approach – DEP PCSM Spreadsheet



- Number of hours to account for infiltration during storm event is limited to 12 hours to remain conservative
- Amount of infiltration is limited by:
  - amount routed to SCM
  - amount stored in bowl after event





# Volume Analysis Approach – Continuous Simulation

- Rain Garden using SWMM
- Most recent 15 years - Philadelphia international airport
- 1 acre
- Green & Ampt equation
- Obtain 2-year/24-hour runoff volumes



Parameter	Post-construction (impervious)	Pre-construction (pervious meadow)
Depression storage value	0.05	0.13
Manning's n-value	0.01	0.15


Saturated hydraulic conductivity: 0.2 in/h

Soil suction: 5 psi

# Volume Analysis Approach – Continuous Simulation

Percent exceedance (ranking) vs. runoff volume


- 2-year storm =  $\frac{1}{2}$  % chance of exceedance in one year (i.e., 50%)
- Took largest daily runoff volume using partial duration probability



# Example site in Philadelphia – Runoff Rate

Percent  
exceedance  
(ranking) vs. runoff  
rate

- 2-year storm =  $\frac{1}{2}$  % chance of exceedance in one year (i.e., 50%)
- Took largest daily runoff volume using partial duration probability




# Volume Analysis Approach – Continuous Simulation

Percent  
exceedance  
vs. runoff  
volume

“C2” scenario  
is same as  
before



Scenario Name	Selected Saturated Hydraulic Conductivity Rate (in/hr)	Selected Soil Suction (psi)
A	1.5	1.9
B	0.6	3.5
C1	0.32	5
C2	0.2	5
C3	0.1	6
D	0.03	8




# Volume Analysis Approach – Continuous Simulation

Percent  
exceedance  
vs. runoff  
volume

“C2” scenario  
is same as  
before




Scenario Name	Selected Saturated Hydraulic Conductivity Rate (in/hr)	Selected Soil Suction (psi)
A	1.5	1.9
B	0.6	3.5
C1	0.32	5
C2	0.2	5
C3	0.1	6
D	0.03	8



# Example site in Philadelphia – Flow Duration


- Number of hours for each flow rate leaving the SCM
- Important for geomorphological concerns
  - 2-year/24-hr preconstruction peak flow is not exceeded in postconstruction
  - Duration of all flows <2-year/24-hr peak
  - All C & D reduced
  - A&B flowrate insignificant






# Example site in Philadelphia – Flow Duration

- Number of hours for each flow rate leaving the SCM
- Important for geomorphological concerns
  - 2-year/24-hr preconstruction peak flow is not exceeded in postconstruction
  - Duration of all flows <2-year/24-hr peak
  - All C & D reduced
  - A&B flowrate insignificant




# Example site in Philadelphia – Ponding

- SCM sizing primarily based on 2-year/24-hour storm
- Need to meet ponding time requirement
  - 90% of the time ponding is under ponding time limit
  - Only needed to adjust footprints for C3 and D soils




# Example site in Philadelphia – Ponding

- SCM sizing primarily based on 2-year/24-hour storm
- Need to meet ponding time requirement
  - 90% of the time ponding is under ponding time limit
  - Only needed to adjust footprints for C3 and D soils



# Continuous Simulation vs. Design Storm

- Continuous simulation approach vs. design storm approach sizing
- Low C and D soils would require underdrains or managed release concept



# Water Quality

- 2006 version:
  - Built BMP according to manual
  - Assumed percent removal
  - Treatment train adds removals – not appropriate.
  - Example Bioinfiltration



<u>Water Quality Functions</u>	
TSS: 85%	
TP: 85%	
NO3: 30%	

- 2022 Version
  - Mass Loading - TSS, TP, TN
  - Using International ASCE BMP Database outflow concentrations (mg/l) for the last water quality SCM
  - Using National Water Stormwater Quality Database for watershed quality concentrations (mg/l)
  - PA has already adopted this new method (PCSM Spreadsheet)



# Water Quality for Land Use

- National Stormwater Quality Database (NSQD)
  - Based on land use from MS4 communities – adapted into BMP database  
(<http://www.bmpdatabase.org/nsqdsta.html>)
  - Provides median concentrations of pollutants





Figure 1. Communities from which data has been obtained and entered in the NSQD, along with EPA Rain Zones.

	Area (acres)	% Imperv.	Precip. Depth (in)	Runoff Depth (in)	Cond. (uS/cm @25°C)	Hardness (mg/L CaCO <sub>3</sub> )	Oil and Grease (mg/L)	pH	Temp. (C)	TDS (mg/L)	TSS (mg/L)	NH <sub>3</sub> (mg/L)	NO <sub>2</sub> +NO <sub>3</sub> (mg/L)	Nitrogen, Total Kjeldahl (mg/L)	Phos., filtered (mg/L)	Phos., total (mg/L)
<b>Open Space (49)</b>																
Number of observations	49	37	41	11	2	8	19	19	2	45	44	32	44	45	44	46
% of samples above detection	100	100	100	100	100	100	36.8	100	100	97.8	95.5	18.8	84.1	71.1	79.6	84.8
Median	85	2.0	0.52	0.05	113	150	1.3	7.70	14.6	125	48.5	0.18	0.59	0.74	0.13	0.31
Coefficient of variation	1.5	1.0	1.2	1.4	0.5	0.6	0.7	0.08	0.7	0.7	1.5	1.24	0.9	0.9	0.9	3.5

\*TN : TKN + NO<sub>2</sub>/3

# Water Quality for SCM


- International Stormwater Best Management Practices Database (BMP Database)
  - Based on SCM type
  - Effluent median concentrations of pollutants



# Water Quality – Point of Interest


## Post-Construction POI

- POI at most downstream Objective A or B SCM Outfall
- Objective C MRC SCM assumed to meet water quality
  - MRC SCMs and Objective A SCM can be assumed met and left unanalyzed (right)
- Objective D not considered to have a WQ Benefit.
  - ASCE International Database does show small reduction in inflow to outflow concentration




# Peak – Design Storm Approach

- PA Code § 102.8.(g)(3):  
*“manage the net change in peak rate for the 2-, 10-, 50-, and 100-year/24-hour storm events in a manner not to exceed preconstruction rates.”*
- Real storm events are often not well represented by the center peaking distribution
- Use Median NOAA-14 Values 24 hour storm



# Peak Rate – Storm of Record Approach

- Select storms from the period of record to represent the 2-, 10-, 50, and 100-year 24 hour NOAA-14 volume.
- 2, 10, 50 yr 24 hr storms must fall within the 90% CI of the NOAA 14 data
- 100 yr 24 hr storms
  - use a value that exceeds the mean.
  - If not available, use one within the 90% CI
  - If not available, use next largest storm greater than 50 year frequency
  - Or use Design storm



Goal is to be able to run data from one data set to address peak.



# Questions?

WRAC

Robert Traver, Villanova University

Mark Bowen, NTM Engineering

Amanda Hess, Villanova University

November 2022